

Quickstart Smart Control SC25 V1.5

Lieferumfang

- 1 St. Lichtsteuerung - Smart Control SC25
- 1 St. Quickstart
(mehr unter daytime.de/service/downloads/)

Installation



Verbinden mit SC25 per WLAN

- Ersten QR-Code scannen und mit WLAN verbinden.
Alternativ: WLAN auswählen und Passwort eingeben



- Zweiten QR-Code scannen und SC25-APP öffnen.
Alternativ: Browser öffnen und Adresse aufrufen



<http://192.168.1.1/> oder
<http://sc25.local/> oder
<http://sc25/>



Funktionstaste und Status LED

- Status LED**
- Funktionstaste**
- Auto ↔ On** - 1 Sek. drücken:
Wechsel zwischen 100% an und Automatik
- WLAN-Reset** - 10 Sek. drücken:
Rücksetzen der WLAN-Einstellungen



Status LED

- Blinkt weiß** - Die Steuerung startet
 - Blau** - Master-Betrieb der Steuerung
(WLAN verfügbar / mit Heimnetz verbunden)
 - Grün** - Slave-Betrieb der Steuerung
 - Blinkt orange** - Software Update läuft
 - Rot** - Beleuchtung zu 100% eingeschaltet
- 🇩🇪

Software Update

Im Menü **Einstellungen** den Button **Manuelles Software-Update** antippen und den Anweisungen folgen.

Hinweis: Ist die SC25 im Heimnetzwerk integriert, werden verfügbare Updates bei bestehender Internetverbindung angezeigt und können automatisch gestartet werden.

Master-Slave-Funktion

Klicke auf **Einstellungen** -> **+ Slave-Steuerung koppeln und den Anweisungen folgen**

Mehrere Steuerungen ins Heimnetz integrieren. Dazu erst die Steuerungen außerhalb des Heimnetzes koppeln und dann die gekoppelten Steuerungen ins Heimnetz integrieren.

🇩🇪

Sicherheitshinweis Safety Instructions



Platzieren Sie das Gerät an einem geeigneten Ort, der sicherstellt, dass Kontakt mit Wasser weitestgehend ausgeschlossen ist.
Place the device in a suitable place, which ensures that contact with water is largely excluded.

**Tropical Heimtierbedarf
Deutschland GmbH**
Bühlfelderweg 12
94239 Ruhmannsfelden
Deutschland

Tel.: +49 (0) 57 67 / 94 14 39-0
Fax: +49 (0) 57 67 / 94 14 39-15

www.daytime.de
info@daytime.de

 Wi-Fi 6 (802.11ax)
802.11b/g/n (2.4 Ghz)
802.11a/n/ac (5 GHz)

daytime[®]

Scope of delivery

- 1 pcs. Light Control - Smart Control SC25
- 1 pcs. Quickstart
(more at daytime.de/service/downloads/)

Installation



Connect with SC25 per Wi-Fi

1

Scan first QR code and connect to Wi-Fi network.
(Or select Wi-Fi network and enter password)



2

Scan the second QR code and open the SC25 app.
Alternatively: Open a browser and go to:



<http://192.168.1.1/> or
<http://sc25.local/> or
<http://sc25/>



Function button and Status LED

Function button

Status LED



Auto ↔ On - press for 1 sec:
Switch between 100% on and automatic
WiFi reset - press for 10 sec:
Resets the Wi-Fi settings

Status LED

-  **Flashing white** - controller is starting up
-  **Blue** - master mode of the light
(Wi-Fi available / connected to the home network)
-  **Green** - slave mode of the light
-  **Flashing orange** - software update running
-  **Red** - Lighting at 100% brightness



Software Update

In the menu **Settings** tap button
Manual software update and follow the instructions.

Note: If the SC25 is integrated into the home network, available updates are displayed when an internet connection is present and can be started automatically.

Master-Slave function

To do so, go to **Settings -> + Pair the slave controller and follow the instructions**

To integrate multiple lights into your home network:
First pair the lights outside the home network, then add the paired lights to the home Wi-Fi network.

